



Lexocad exercise : BIM tutorial 3.1

① Open an IFC file with double click or with file/open...
=> IFC is displayed in lexocad BIM converter



② From Lexocad BIM Converter
- Save to obtain an lxz file
- Import (or not) settings



③ IFC is now converted in a lexocad file
It is then possible to export the 3d model
in cadwork 3d, using the 3d icon



With right click (R) on 3d icon it
is possible to define some settings =>

